



- For EPN**
- C79/C90/C91/C92
 - CX3900/CX4900/Cx5600 /CX5900/CX6900F
 - /CX5000/CX6000
 - D78/D92/
 - DX4000/DX4050/DX5000 /DX5050/DX6000/DX6050 /Dx7000f

- 💧 Continuous ink system
- 💧 Continuous ink supply system
- 💧 Continuous ink flow system
- 💧 Continuous ink feed system
- 💧 Bulk ink system

Unpacking Instruction

1. CIS ink system (Continuous ink system) 1 Set
2. Pipeline Clincher or Arm Support 1 Set
3. Installation Instruction 1 Copy
4. Syringe 1 Set


Note

1. Not drinkable, keep it out of the reach of children
2. Avoid exposure to direct sunshine and don't keep it in the high or freezing temperature.
3. Avoid collision and fallen down.
4. Please do not take out the cartridges at random after installing the CIS ink system.
5. Using it in the temperature of 10-40°C
6. The CIS ink system has passed the strict compatible checking, so we suggest to use our ink and cartridges to keep the printing quality.
7. Mix two different brand ink into the CIS ink system is not recommended.


8. Keep the ink tanks and printer in the same level. Do not place the tanks higher or lower than their printer

Refilling ink


ALL OPEN



FILL INK TO THIS LEVEL
(Only for reference)



ALL OPEN



FILL INK HIGHT TO FULL
(No recommend)

When you want to filling ink, firstly, please pull out the rubber plugs from the fill-hole of the ink tank; use a common syringe to fill ink (please see the step as picture 2); and then, pull out rubber plugs from the CIS cartridge and use a syringe to draw air, pull the syringe position for air-removing (please see the step as picture 3), then the ink will flow into the ink cartridges from the tanks automatically. After filled, you need to stuff all holes with the rubber plugs.


Tanks working :

OPEN 1 CLOSE 2




CAN FILL INK ANY TIME,
WHEN INK IS TOO LOW,
MUST FILL INK.

CLOSE ALL



AFTER FILLED OR MOVED TANKS



CLOSE ALL

OPEN 1 CLOSE 2



Ok
WHEN WORKING,
OPEN SMALL PLUG,
CLOSE BIG PLUG


- 1 Press the Power Button When the cartridge moves, pull out the power cord.. ▲



- 2 Open the carriage cover to certain angle (about 60 degree). Then use a screwdriver to insert into the joint as the picture shows.
Turn the screwdriver clockwise and lift the cover and then it can be removed.
Make the right side of the cover separate with the carriage.



- 3 Take out the original carts.
Move the carriage to the leftside
Insert the CISS cartridge in the same way as the picture shows.
Move the carriage to its original place
Then install the CISS carts well.




- 4 Stick the support arm in the place as the picture shows.
Then stick another support arm over the first one.
Stick the short support arm parallelly as the above picture shows.



- 5 Clip the tube
Move the carriage to the rightmost and make sure that the tube can be straight.
Installation is finished.

Notice for cartridges:



The ink will be showed less and lessr when printing, as the original cartridges.
The chips for CIS can auto reset when the printer show '0' capacity ink.
If use for a long time ,the computer tells you to replace cartridge doesn't work,
Power off the printer for 1 minute, then restart ok.